

# Stopwatch

## Description

The purpose of the stopwatch is to track the time passed after the press of a button displayed in "HH:MM:SS.hh" format. The stopwatch is precise to 1/100th of a second, accurate to  $\pm 1$  second over a 1 hour period. A piezo buzzer generates a 1kHz tone for 100ms at the start of each second.

## Operating Conditions

Operating voltage range of the device: 4V to 5.5V

Operating temperature: +20°C to +80°C

Storage temperature: -65°C to +150°C

Maximum DC Current per I/O pin: 40.0mA

## Setup Instructions

To operate the device, connect VCC (Pin 7) to a voltage source that is within the operating voltage range, GND (Pin 8, 22) to ground. *Refer to Figure 1 for the device's schematic.*




Figure 1: Schematic

Farez Halim 1423780

Tamara Oldham 1440376

LAB H11

## Usage Instructions

Press the button to start the stopwatch. Pressing the button for a short time while it's running pauses the stopwatch. A short press while it's paused will resume it, and a long press while paused resets the stopwatch.

## Testing